

INSTALLATION INSTRUCTIONS

⚠ WARNING

Improper installation, adjustment, alteration, service or maintenance can cause property damage, personal injury or loss of life. Installation and service must be performed by a qualified installer, service agency or the gas supplier

RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE

Table Of Contents


Dimensions	Page 2
Shipping and Packing List	Page 3
General	Page 3
Requirements	Page 3
Unit Support	Page 4
Duct Connection	Page 5
Rigging Unit For Lifting	Page 5
Horizontal Air Discharge	Page 6
Condensate Drains	Page 6

KHA024 (2 TON)
KHA030 (2-1/2 TON)
KHA036 (3 TON)
KHA048 (4 TON)
KHA060 (5 TON)
KHA072 (6 TON)


HEAT PUMP PACKAGED UNITS
 506002-01
 4/2012
 Supersedes 11/2011

Electrical Connections	Page 8
Blower Operation and Adjustments	Page 10
Start-Up	Page 18
Defrost Control Board	Page 21
Service	Page 21


KHA024, 030, 036, 048, 060, 072 PARTS ARRANGEMENT




KHA024, 030, 036, 048, 060, 072 DIMENSIONS in (mm)




TOP VIEW (Base)



END VIEW



SIDE VIEW



BACK VIEW

Shipping and Packing List

Package 1 of 1 contains:

1 - Assembled unit

Check unit for shipping damage. Receiving party should contact last carrier immediately if shipping damage is found.

General

These instructions are intended as a general guide and do not supersede local codes in any way. Authorities having jurisdiction should be consulted before installation.

Availability of units and options varies by brand.

Requirements

The KHA unit is ETL/CSA certified as a heat pump with cooling and with or without auxiliary electric heat for non-residential use only at the clearances to combustible materials as listed on the unit nameplate and in figure 1.

Installation of KHA heat pumps must conform with standards in National Fire Protection Association (NFPA) "Standard for Installation of Air Conditioning and Ventilating Systems NFPA No. 90A," "Standard for Installation of Residence Type Warm Air Heating and Air conditioning Systems NFPA No. 90B," local municipal building codes and manufacturer's installation instructions.




FIGURE 1

¹ Unit Clearance	A in. (mm)	B in. (mm)	C in. (mm)	D in. (mm)	Top Clearance
Service Clearance	36 (914)	36 (914)	36 (914)	36 (914)	Unob- structed
Minimum Opera- tion Clearance	36 (914)	36 (914)	36 (914)	36 (914)	Unob- structed

Note - Entire perimeter of unit base requires support when elevated above mounting surface.

¹ **Service Clearance** - Required for removal of serviceable parts.
Minimum Operation Clearance - Required clearance for proper unit operation.

⚠ NOTICE

Roof Damage!
This system contains both refrigerant and oil. Some rubber roofing material may absorb oil, causing the rubber to swell. Bubbles in the rubber roofing material can cause leaks. Protect the roof surface to avoid exposure to refrigerant and oil during service and installation. Failure to follow this notice could result in damage to roof surface.

The National Electric Code (ANSI/NFPA No. 70-1984) is available from:

National Fire Protection Association
 1 Batterymarch Park
 PO Box 9101
 Quincy, MA 02269-9101

Installation of ETL/CSA certified units must also conform with current standard C273.5 "Installation Requirements for Heat Pumps" and applicable local codes. Authorities having jurisdiction should be consulted before installation.

Use of this unit as a construction heater or air conditioner is not recommended during any phase of construction. Very low return air temperatures, harmful vapors and operation of the unit with clogged or misplaced filters will damage the unit.

If this unit has been used for heating or cooling of buildings or structures under construction, the following conditions must be met or the warranty will be void:

- A room thermostat must control the unit. The use of fixed jumpers that will provide continuous heating or cooling is not allowed.
- A pre-filter must be installed at the entry to the return air duct.
- The return air duct must be provided and sealed to the unit.
- Return air temperature range between 55°F (13°C) and 80°F (27°C) must be maintained.
- Air filters must be replaced and pre-filter must be removed upon construction completion.
- The unit components, duct system, air filters and evaporator coil must be thoroughly cleaned following final construction clean-up.
- The unit operating conditions (including airflow, cooling operation, and heating operation) must be verified according to these installation instructions.

⚠ CAUTION

Danger of sharp metallic edges. Can cause injury. Take care when servicing unit to avoid accidental contact with sharp edges.

⚠ WARNING



Electric shock hazard and danger of explosion. Can cause injury, death or product or property damage. Turn off electrical power to unit before performing any maintenance or servicing operations on the unit.

⚠ IMPORTANT

The Clean Air Act of 1990 bans the intentional venting of refrigerant (CFC's and HCFC's) as of July 1, 1992. Approved methods of recovery, recycling or reclaiming must be followed. Fines and/or incarceration may be levied for non-compliance.

Unit Support

NOTE - Securely fasten roof frame to roof per local codes.

KH 024, 030, 036, 048, 060 units are installed on T1CURB frames. KH 072 units are installed on K1CURB or T1CURB frames. K1CURB is a full-perimeter curb for KH 072 units; KH 072 will overhang T1CURB frame.

A - Downflow Discharge Application

Roof Mounting with T1CURB or K1CURB

- 1- The T1CURB/K1CURB roof mounting frame must be installed, flashed and sealed in accordance with the instructions provided with the frame.
- 2- The T1CURB/K1CURB roof mounting frame should be square and level to 1/16" per linear foot (5mm per linear meter) in any direction.
- 3- Duct must be attached to the roof mounting frame and not to the unit; supply and return plenums must be installed before setting the unit.

Installer's Roof Mounting Frame

Many types of roof frames can be used to install the unit, depending upon different roof structures. Items to keep in mind when using the building frame or supports are:

- 1- The unit base is fully enclosed and insulated, so an enclosed frame is not required.
- 2- The frames or supports must be constructed with non-combustible materials and should be square and level to 1/16" per linear foot (5mm per linear meter) in any direction.
- 3- Frame or supports must be high enough to prevent any form of moisture from entering unit. Recommended minimum frame height is 14" (356mm).
- 4- Duct must be attached to the roof mounting frame and not to the unit. Supply and return plenums must be installed before setting the unit.
- 5- Units require support along all four sides of unit base. Supports must be constructed of steel or suitably treated wood materials.

NOTE-When installing unit on a combustible surface for downflow discharge applications, the T1CURB/K1CURB roof mounting frame is required.

B - Horizontal Discharge Applications

- 1- Units which are equipped with an optional economizer and installed in horizontal airflow applications must use a horizontal conversion kit.
- 2- Specified installation clearances must be maintained when installing units. Refer to figure 1.
- 3- Top of support slab should be at least 4" (102mm) above the finished grade and located so no run-off water from higher ground can collect around the unit.
- 4- Units require support along all four sides of unit base. Supports must be constructed of steel or suitably treated wood materials.

Duct Connection

All exterior ducts, joints, and openings in roof or building walls must be insulated and weatherproofed with flashing and sealing compounds in accordance with applicable codes. Any duct passing through an unconditioned space must be insulated.



CAUTION

In downflow applications, do not drill or punch holes in base of unit. Leaking in roof may occur if unit base is punctured.

Rigging Unit For Lifting

- 1- Detach wooden base protection before rigging.
- 2- Remove all six base protection brackets before setting unit.
- 3- Connect rigging to the unit base using both holes in each corner. See figure 2.
- 4- All panels must be in place for rigging.
- 5- Place field-provided H-style pick in place just above top edge of unit. Frame must be of adequate strength and length. (H-style pick prevents damage to unit.)




FIGURE 2

Horizontal Air Discharge

Unit is shipped with panels covering the horizontal supply and return air openings. Remove horizontal covers and place over downflow openings for horizontal air discharge. See figure 3. Secure in place with sheet metal screws.




FIGURE 3

Units Equipped With An Optional Economizer -

- 1- Remove the horizontal supply air cover and position over the downflow supply air opening. Secure with sheet metal screws.
- 2- Leave the horizontal return air cover in place.
- 3- Locate the separately ordered horizontal air discharge kit. Place the kit panel over the downflow return air opening.
- 4- Remove and retain the barometric relief dampers and lower hood.
- 5- Install return air duct beneath outdoor air intake. See figure 4. Install barometric relief damper in lower hood and install in duct as shown in figure 4.




FIGURE 4

Condensate Drains

Make drain connection to the drain coupling provided on unit. Older model units have a 3/4" N.P.T. coupling and newer model units have a 1" N.P.T. coupling.

Note - The drain pan is made with a glass reinforced engineered plastic capable of withstanding typical joint torque but can be damaged with excessive force. Tighten pipe nipple hand tight and turn an additional quarter turn.

A trap must be installed between drain connection and an open vent for proper condensate removal. See figure 5 or 6. It is sometimes acceptable to drain condensate onto the roof or grade; however, a tee should be fitted to the trap to direct condensate downward. The condensate line must be vented. Check local codes concerning condensate disposal. Refer to pages 1 and 2 for condensate drain location.




FIGURE 5




FIGURE 6

Units are shipped with the drain coupling facing the front of the unit. Condensate can be drained from the back or bottom of the unit with the following modifications. The unit can be installed in either downflow or horizontal air discharge regardless of condensate drain location.

Rear Drain Connection

- 1- Remove the condensate drain mullion. See figure 7. Remove the two panels on each side of the mullion.




FIGURE 7

If the unit has hinged panels, two hinge screws must be removed in addition to the mullion screws. See figure 8.




FIGURE 8

- 2- Lift the front edge of the drain pan and slide pan out of unit. See figure 9.




FIGURE 9

- 3- Make sure the cap over the unit bottom drain hole is secure.
- 4- Rotate the drain pan until the downward slope is toward the back of the unit. Slide the drain pan back into the unit. Be careful not to dislodge the cap over the bottom drain hole.
- 5- From the back side of the unit, pull the drain pan coupling through the rear condensate opening.
- 6- Replace the condensate drain mullion.

Bottom Drain Connection

- 1- Remove the condensate drain mullion. See figure 7.
- 2- Lift the front edge of the drain pan and slide pan out of unit. See figure 9.
- 3- Turn the drain pan upside down and drill a pilot hole through the bottom of the drain pan in the center of the coupling. See figure 10.
- 4- From the inside of the pan, use a Vari-Bit® bit to enlarge the hole to 7/8". Do not damage coupling threads.
- 5- Remove the cap over the unit bottom drain hole.
- 6- Slide the drain pan back into the unit.
- 7- From the back side of the unit, pull the drain pan coupling through the rear condensate opening.
- 8- From the front side of the unit, move the drain pan until the bottom coupling settles into the unit bottom drain opening. Once in place, check to make sure the coupling is still positioned through the rear condensate drain hole.
- 9- Use a field-provided 3/4" plug to seal side drain connection.
- 10- Replace the condensate drain mullion.




FIGURE 10

Electrical Connections

POWER SUPPLY

Do not apply power or close disconnect switch until installation is complete. Refer to start-up directions. Refer closely to unit wiring diagram. Figure 12 shows a typical unit wiring diagram.

Refer to unit nameplate for minimum circuit ampacity and maximum fuse size.

- 1- Units are factory-wired for 240,460,575 volt supply. **For 208V supply**, remove the insulated terminal cover from the 208V terminal on the control transformer. Move the wire from the transformer 240V terminal to the 208V terminal. Place the insulated terminal cover on the unused 240V terminal.
- 2- Route power through the bottom power entry area and connect to TB2. Secure power wiring with factory-installed wire ties provided in control box. See unit wiring diagram.

CONTROL WIRING

A - Thermostat Location

Room thermostat mounts vertically on a standard 2" X 4" handy box or on any non-conductive flat surface.

Locate thermostat approximately 5 feet (1524 mm) above the floor in an area with good air circulation at average temperature. Avoid locating the room thermostat where it might be affected by:

- drafts or dead spots behind doors and in corners
- hot or cold air from ducts
- radiant heat from sun or appliances
- concealed pipes and chimneys

IMPORTANT - Unless field thermostat wires are rated for maximum unit voltage, they must be routed away from line voltage wiring. Use wire ties located near the lower left corner of the controls hat section to secure thermostat cable.

B - Control Wiring

- 1- Route thermostat cable or wires from subbase to control area above compressor (refer to unit dimensions to locate bottom and side power entry). Use 18 AWG wire for all applications using remotely installed electro-mechanical and electronic thermostats.
- 2- Install thermostat assembly in accordance with instructions provided with thermostat.
- 3- Connect thermostat wiring to TB1 terminal control board on the lower side of the controls hat section. Wire as shown in figure 11 for electro-mechanical and electronic thermostats. If using other temperature control devices or energy management systems see instructions and wiring diagram provided by manufacturer.

IMPORTANT-Terminal connections at the wall plate or subbase must be made securely. Loose control wire connections may allow unit to operate but not with proper response to room demand.




FIGURE 11

TYPICAL KHA UNIT WIRING SCHEMATIC

24V POWER

NOTE-FOR USE WITH COPPER CONDUCTORS ONLY
REFER TO UNIT RATING PLATE FOR MINIMUM CIRCUIT
AMPACITY AND MAXIMUM OVERCURRENT PROTECTION SIZE

S40 IS NOT REQ'D ON 072 UNITS

ECONOMIZER


BLOWER(G)

HEAT 1(W1)

HEAT 2(W2)

COOL 1(Y1)

24V COMMON



KEY	DESCRIPTION	COMPONENT
A6	CONTROL-SOLID STATE ENTHALPY	
A17	DETECTOR-SMOKE, RETURN AIR	
A64	DETECTOR-SMOKE, SUPPLY AIR	
B1	COMPRESSOR	
B3	MOTOR-BLOWER	
B4	MOTOR-OUTDOOR FAN	
B7	MOTOR-DAMPER ECONOMIZER	
B10	MOTOR-EXHAUST FAN	
C1	CAPACITOR-OUTDOOR FAN	
C4	CAPACITOR-BLOWER MOTOR	
C6	CAPACITOR-EXHAUST FAN	


IMPORTANT: TO PREVENT MOTOR BURNOUT, NEVER
CONNECT MORE THAN ONE MOTOR LEAD TO ANY
ONE CONNECTION. TAPE UNUSED MOTOR LEADS

CONNECTIONS FOR REMOTE MOUNTED SMOKE DETECTORS
A17 & A64, MAX LOAD 0.1VA 24VAC CLASS II EACH

A17 ONLY OR A64 ONLY HOOKUP

A17 AND A64 HOOKUP

C88	CIRCUIT BREAKER-TRANSFORMER T1
CMC1	TIMER-DEFROST, COMPRESSOR 1
F6	FUSE-EXHAUST FAN
HRI	HEATER COMPRESSOR
J2	JACK-HEAT
J3	JACK-UNIT ECONOMIZER
J18	JACK-EXHAUST FAN
J35	JACK-TEST
J132	JACK-BLOWER, EXHAUST FAN MOTOR
K1,-1	CONTACTOR-COMPRESSOR
K3,-1	CONTACTOR-BLOWER
K8,-1,2	RELAY-TRANSFER 1
K58,-1	RELAY-LOW AMBIENT KIT
K65,-1,2	RELAY-EXHAUST FAN
L1	VALVE-REVERSING
P4	PLUG-ECONOMIZER
P18	PLUG-EXHAUST FAN
P35	PLUG-TEST
P43	PLUG-BLOWER MOTOR
P45	PLUG-INPUT
P132	PLUG-BLOWER, EXHAUST FAN MOTOR
S3	SWITCH-LIMIT, LOW COMP 1 /COMPRESSOR MONITOR
S4	SWITCH-LIMIT, HI PRESS (MANUAL RESET)
S6	SWITCH-DEFROST, COMPRESSOR 1
S11	SWITCH-LOW PRESS, LOW AMB KIT
S40	THERMOSTAT-CRANKCASE
S49	SWITCH-FREEZESTAT
S74	SWITCH-FIRESTAT 1
S75	SWITCH-FIRESTAT 2
S87	SWITCH-LOW PRESS, COMPRESSOR 1
T1	TRANSFORMER-CONTROL



DISCONNECT ALL POWER BEFORE SERVICING

NOTE-IF ANY WIRE IN THIS APPLIANCE IS REPLACED, IT
MUST BE REPLACED WITH WIRE OF LIKE SIZE, RATING,
TERMINATION AND INSULATION THICKNESS.

WARNING-ELECTRIC SHOCK HAZARD, CAN CAUSE INJURY
OR DEATH. UNIT MUST BE GROUNDED IN
ACCORDANCE WITH NATIONAL AND LOCAL CODES

← DENOTES OPTIONAL COMPONENTS

— LINE VOLTAGE FIELD INSTALLED

WIRING DIAGRAM 11/07

COOLING UNITS-PACKAGED

KHA, THA-036,048,060,072-Y

208-230/60/3

COOLING SECTION B33

Supersedes Form No. New Form No. 535,026W

© 2007 Litho U.S.A.

FIGURE 12

Blower Operation and Adjustments

Units are equipped with direct or belt drive blowers; available drive varies by model.

⚠️ IMPORTANT

Three phase scroll compressors must be phased sequentially for correct compressor and blower rotation. Follow "COOLING START-UP" section of installation instructions to ensure proper compressor and blower operation.

A - Blower Operation

- 1- Set thermostat or temperature control device fan switch to **AUTO** or **ON**. With fan switch in **ON** position, blower will operate continuously. With fan switch in **AUTO** position, the blower will cycle with demand.
- 2- Blower and entire unit will be off when thermostat or temperature control device system switch is in **OFF** position.

B - Determining Unit CFM - Direct Drive Blowers

- 1- The following measurements must be made with air filters in place.
- 2- With all access panels in place, measure static pressure external to unit (from supply to return). Add any additional air resistance for options and accessories shown in 8.
- 3- Use figure 13 to determine the factory set blower speed.

BLOWER SPEED FACTORY SETTINGS

036 Units	024, 030, 048 Units	060 Units
<input type="checkbox"/> 1 Com	<input type="checkbox"/> 1 Com	<input type="checkbox"/> 1 Com
<input type="checkbox"/> 2 Hi	<input type="checkbox"/> 2 Hi	<input type="checkbox"/> 2 Hi
<input type="checkbox"/> 3 Med	<input type="checkbox"/> 3 Med*	<input type="checkbox"/> 3 Low*
<input type="checkbox"/> 4 Low*	<input type="checkbox"/> 4 Low	<input type="checkbox"/> 4 Unused

*Factory Setting

FIGURE 13

- 4- Use tables 2 through 7, the measured static pressure, and the factory-set blower speed to determine CFM. If CFM is lower than the design specified CFM, move the lead from speed tap 3 or 4 to speed tap 2. See figure 14. Refer to table 9 for minimum airflow when electric heat is installed.

For 460/575V units, remove the isolation lead from speed tap 2 before moving the wire to speed tap 2. Tape the exposed end of the isolation lead and secure away from other components.




FIGURE 14

C - Determining Unit CFM - Belt Drive Blowers

- 1- The following measurements must be made with air filters in place.
- 2- With all access panels in place, measure static pressure external to unit (from supply to return).
- 3- Measure the indoor blower wheel RPM.
- 4- Referring to tables 3 through 7, use static pressure and RPM readings to determine unit CFM. Use table 8 when installing units with any of the options or accessories listed. Refer to table 9 for minimum airflow when electric heat is installed.
- 5- The blower RPM can be adjusted at the motor pulley. Loosen Allen screw and turn adjustable pulley clockwise to increase CFM. Turn counterclockwise to decrease CFM. See figure 16. Do not exceed minimum and maximum number of pulley turns as shown in table 1.

**TABLE 1
MINIMUM AND MAXIMUM PULLEY ADJUSTMENT**

Belt	Min. Turns Open	Maxi. Turns Open
A Section	No minimum	5

D - Blower Belt Adjustment

Maximum life and wear can be obtained from belts only if proper pulley alignment and belt tension are maintained. Tension new belts after a 24-48 hour period of operation. This will allow belt to stretch and seat grooves. Make sure blower and motor pulley are aligned as shown in figure 15.




FIGURE 15

- 1- Loosen four bolts securing motor base to mounting frame. See figure 16.
- 2- *To increase belt tension -*
Slide blower motor downward to tighten the belt. This increases the distance between the blower motor and the blower housing.
- To loosen belt tension -*
Slide blower motor upward to loosen the belt. This decreases the distance between the blower motor and the blower housing.
- 3- Tighten four bolts securing motor base to the mounting frame.




FIGURE 16

E - Check Belt Tension

Overtensioning belts shortens belt and bearing life. Check belt tension as follows:

- 1- Measure span length X. See figure 17.
- 2- Apply perpendicular force to center of span (X) with enough pressure to deflect belt 1/64" for every inch of span length or 1.5mm per 100mm of span length.

Example: Deflection distance of a 40" span would be 40/64" or 5/8".

Example: Deflection distance of a 400mm span would be 6mm.

- 3- Measure belt deflection force. For a used belt, the deflection force should be 5 lbs. (35kPa). A new belt deflection force should be 7 lbs. (48kPa).

A force below these values indicates an undertensioned belt. A force above these values indicates an overtensioned belt.

F-Field-Furnished Blower Drives

For field-furnished blower drives, use tables 3 through 7 to determine BHP and RPM required. Reference table 10 to determine the drive kit number and figure 11 for drive kit specifications..




FIGURE 17

**TABLE 2
DIRECT DRIVE BLOWER PERFORMANCE**

External Static Pressure (in. w.g.)	Air Volume (cfm) at Various Blower Speeds					
	208 VOLTS			230 VOLTS		
	High	Medium	Low	High	Medium	Low
2 and 2.5 Ton Standard Efficiency (Down-Flow)				KHA024S and KHA030S		
0.0	1230	975	845	1425	1125	910
0.1	1220	940	815	1395	1110	875
0.2	1205	910	775	1375	1085	845
0.3	1185	880	730	1350	1055	815
0.4	1155	845	680	1320	1010	780
0.5	1115	800	---	1280	955	740
0.6	1060	750	---	1225	895	690
0.7	985	685	---	1150	830	---
0.8	890	---	---	1050	755	---
0.9	770	---	---	920	680	---
1.0	---	---	---	760	---	---
2 and 2.5 Ton Standard Efficiency (Horizontal)				KHA024S and KHA030S		
0.0	1165	925	800	1350	1065	865
0.1	1155	895	770	1325	1055	830
0.2	1140	865	735	1300	1030	800
0.3	1125	835	695	1280	1000	770
0.4	1095	800	645	1250	955	740
0.5	1055	760	---	1215	905	700
0.6	1005	710	---	1160	850	655
0.7	935	650	---	1090	785	---
0.8	845	---	---	995	720	---
0.9	730	---	---	875	645	---
1.0	---	---	---	720	---	---

**TABLE 3
BELT DRIVE BLOWER PERFORMANCE**

0.10 to 1.00 in. w.g.

3 Ton Standard Efficiency (Down-Flow)

KHA036S

Air Volume (cfm)	External Static (in.w.g.)															
	0.10		0.20		0.30		0.40		0.50		0.60		0.70		0.80	
	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP
	Field Furnished				Low Static - Drive Kit #1								Kit 5			
900	485	0.10	595	0.15	690	0.20	780	0.30	860	0.40	930	0.50	1000	0.60	1065	0.75
1000	520	0.10	615	0.20	705	0.25	790	0.35	870	0.45	945	0.55	1010	0.65	1075	0.75
1100	550	0.15	640	0.20	725	0.30	805	0.35	885	0.45	955	0.55	1020	0.70	1085	0.80
1200	585	0.20	665	0.25	745	0.30	825	0.40	900	0.50	965	0.60	1030	0.70	1095	0.85
1300	620	0.20	695	0.30	770	0.35	845	0.45	915	0.55	980	0.65	1045	0.75	1105	0.90
1400	660	0.25	730	0.35	795	0.40	865	0.50	935	0.60	995	0.70	1060	0.80	1120	0.95
1500	695	0.30	760	0.40	825	0.45	890	0.55	955	0.65	1015	0.75	1075	0.85	1135	1.00

0.90 to 1.60 in. w.g.

3 Ton Standard Efficiency (Down-Flow)

KHA036S

Air Volume (cfm)	External Static (in.w.g.)															
	0.90		1.0		1.10		1.20		1.30		1.40		1.50		1.60	
	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP
	High Static - Drive Kit #5						Field Furnished									
900	1125	0.85	1180	1.00	1230	1.10	1285	1.25	1330	1.35	1380	1.50	1425	1.65	1465	1.80
1000	1130	0.90	1190	1.00	1240	1.15	1295	1.30	1340	1.40	1390	1.60	1435	1.75	1475	1.85
1100	1140	0.90	1200	1.05	1250	1.20	1300	1.35	1350	1.50	1400	1.65	1445	1.80	1485	1.95
1200	1150	0.95	1210	1.10	1260	1.25	1310	1.40	1360	1.55	1410	1.70	1455	1.85	1495	2.00
1300	1165	1.00	1220	1.15	1270	1.30	1320	1.45	1370	1.60	1415	1.75	1465	1.90	1505	2.05
1400	1175	1.05	1230	1.20	1280	1.35	1330	1.50	1380	1.65	1425	1.80	1470	1.95	1515	2.15
1500	1190	1.15	1240	1.25	1295	1.40	1345	1.55	1390	1.70	1435	1.90	1480	2.05	1525	2.20

0.10 to 0.80 in. w.g.

3 Ton Standard Efficiency (Horizontal)

KHA036S

Air Volume (cfm)	External Static (in.w.g.)															
	0.10		0.20		0.30		0.40		0.50		0.60		0.70		0.80	
	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP
	Field Furnished				Low Static - Drive Kit #1											
900	480	0.10	570	0.15	655	0.20	735	0.30	810	0.35	875	0.45	940	0.55	1000	0.65
1000	520	0.15	595	0.15	675	0.25	750	0.30	820	0.40	890	0.50	950	0.60	1010	0.70
1100	555	0.15	625	0.20	695	0.25	765	0.35	835	0.45	900	0.50	960	0.60	1020	0.75
1200	595	0.20	660	0.25	725	0.30	790	0.40	850	0.45	915	0.55	975	0.65	1030	0.75
1300	635	0.25	690	0.30	750	0.35	810	0.40	870	0.50	930	0.60	990	0.70	1045	0.80
1400	675	0.30	730	0.35	785	0.40	840	0.50	895	0.55	950	0.65	1005	0.75	1060	0.85
1500	720	0.35	765	0.40	815	0.45	870	0.55	920	0.60	970	0.70	1025	0.80	1075	0.95

0.90 to 1.60 in. w.g.

3 Ton Standard Efficiency (Horizontal)

KHA036S

Air Volume (cfm)	External Static (in.w.g.)															
	0.90		1.0		1.10		1.20		1.30		1.40		1.50		1.60	
	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP
	High Static - Drive Kit #5										Field					
900	1055	0.75	1105	0.90	1155	1.00	1200	1.10	1245	1.25	1285	1.35	1325	1.50	1365	1.60
1000	1065	0.80	1115	0.90	1165	1.05	1210	1.15	1255	1.30	1300	1.40	1340	1.55	1380	1.70
1100	1075	0.85	1125	0.95	1175	1.10	1220	1.20	1265	1.35	1310	1.50	1350	1.60	1395	1.75
1200	1085	0.90	1135	1.00	1185	1.15	1235	1.25	1280	1.40	1320	1.55	1365	1.70	1405	1.85
1300	1095	0.95	1145	1.05	1195	1.20	1245	1.30	1290	1.45	1330	1.60	1375	1.75	1415	1.90
1400	1110	1.00	1160	1.10	1210	1.25	1255	1.40	1300	1.50	1340	1.65	1385	1.80	1425	1.95
1500	1125	1.05	1175	1.15	1220	1.30	1265	1.45	1310	1.60	1355	1.75	1395	1.85	1435	2.05

**TABLE 4
BELT DRIVE BLOWER PERFORMANCE**

0.10 to 0.80 in. w.g.

4 Ton Standard Efficiency (Down-Flow)

KHA048S

Air Volume (cfm)	External Static (in.w.g.)															
	0.10		0.20		0.30		0.40		0.50		0.60		0.70		0.80	
	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP
	Field Furnished						Low Static - Drive Kit #2									
1200	580	0.15	665	0.20	740	0.30	820	0.35	890	0.45	955	0.53	1020	0.63	1080	0.73
1300	620	0.20	690	0.25	765	0.30	835	0.40	905	0.48	970	0.58	1035	0.68	1090	0.78
1400	655	0.25	725	0.30	795	0.35	860	0.45	925	0.53	990	0.63	1050	0.73	1105	0.83
1500	690	0.28	755	0.35	820	0.40	884	0.50	945	0.58	1005	0.68	1065	0.78	1120	0.88
1600	730	0.33	790	0.40	850	0.48	910	0.55	970	0.65	1025	0.73	1085	0.83	1140	0.93
1700	765	0.40	825	0.48	880	0.53	935	0.60	995	0.70	1050	0.80	1105	0.90	1155	1.03
1800	805	0.48	860	0.53	910	0.60	970	0.70	1020	0.80	1075	0.88	1125	0.98	1175	1.08
1900	845	0.53	895	0.63	945	0.68	995	0.78	1050	0.85	1100	0.95	1150	1.08	1200	1.18
2000	885	0.63	930	0.68	980	0.78	1030	0.88	1080	0.95	1125	1.05	1175	1.15	1220	1.28

0.90 to 1.60 in. w.g.

4 Ton Standard Efficiency (Down-Flow)

KHA048S

Air Volume (cfm)	External Static (in.w.g.)															
	0.90		1.00		1.10		1.20		1.30		1.40		1.50		1.60	
	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP
	High Static - Drive Kit #6													Field		
1200	1135	0.83	1190	0.95	1240	1.05	1290	1.20	1335	1.30	1380	1.43	1425	1.58	1470	1.70
1300	1145	0.88	1200	1.00	1250	1.10	1300	1.25	1350	1.38	1395	1.50	1440	1.63	1480	1.78
1400	1160	0.93	1215	1.05	1265	1.18	1310	1.30	1360	1.43	1405	1.57	1450	1.68	1490	1.83
1500	1175	0.98	1225	1.10	1275	1.25	1325	1.35	1370	1.50	1415	1.63	1460	1.78	1500	1.93
1600	1190	1.08	1240	1.18	1290	1.30	1340	1.45	1385	1.55	1430	1.70	1470	1.83	1515	2.00
1700	1205	1.13	1260	1.25	1305	1.38	1355	1.50	1400	1.65	1440	1.78	1485	1.93	1525	2.08
1800	1225	1.23	1275	1.33	1320	1.45	1370	1.60	1415	1.75	1455	1.85	1500	2.03	1540	2.18
1900	1245	1.28	1290	1.43	1340	1.55	1385	1.70	1425	1.80	1470	1.95	1510	2.10	1555	2.28
2000	1270	1.38	1315	1.53	1355	1.65	1400	1.78	1445	1.93	1485	2.05	1525	2.20	1565	2.38

0.10 to 0.80 in. w.g.

4 Ton Standard Efficiency (Horizontal)

KHA048S

Air Volume (cfm)	External Static (in.w.g.)															
	0.10		0.20		0.30		0.40		0.50		0.60		0.70		0.80	
	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP
	Field Furnished						Low Static - Drive Kit #2									
1200	590	0.18	655	0.20	720	0.25	780	0.35	845	0.40	905	0.50	965	0.58	1020	0.68
1300	630	0.20	685	0.25	745	0.30	805	0.38	865	0.45	925	0.52	980	0.60	1034	0.70
1400	675	0.25	725	0.30	780	0.35	835	0.43	890	0.50	945	0.53	995	0.65	1050	0.75
1500	715	0.33	760	0.35	810	0.40	860	0.50	914	0.55	965	0.63	1015	0.73	1065	0.80
1600	755	0.38	800	0.43	845	0.48	895	0.55	940	0.60	990	0.70	1040	0.80	1085	0.88
1700	795	0.45	835	0.50	880	0.55	925	0.63	970	0.70	1015	0.78	1060	0.85	1105	0.95
1800	840	0.53	875	0.58	915	0.63	960	0.70	1000	0.78	1045	0.85	1085	0.93	1130	1.03
1900	880	0.63	920	0.68	955	0.73	995	0.80	1035	0.88	1075	0.95	1115	1.03	1155	1.13
2000	925	0.73	960	0.78	995	0.83	1030	0.90	1070	0.98	1105	1.05	1145	1.13	1180	1.23

0.90 to 1.60 in. w.g.

4 Ton Standard Efficiency (Horizontal)

KHA048S

Air Volume (cfm)	External Static (in.w.g.)															
	0.90		1.0		1.10		1.20		1.30		1.40		1.50		1.60	
	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP
	Kit #2						High Static - Drive Kit #6									
1200	1070	0.75	1120	0.85	1170	0.98	1215	1.08	1255	1.18	1300	1.30	1340	1.40	1380	1.55
1300	1085	0.80	1135	0.90	1180	1.00	1225	1.13	1270	1.23	1310	1.35	1350	1.48	1390	1.60
1400	1100	0.85	1145	0.98	1195	1.08	1240	1.18	1280	1.28	1324	1.43	1365	1.53	1405	1.68
1500	1115	0.90	1160	1.03	1205	1.13	1250	1.23	1295	1.35	1335	1.48	1375	1.63	1415	1.73
1600	1130	0.98	1175	1.08	1220	1.18	1265	1.33	1305	1.43	1350	1.55	1390	1.68	1425	1.80
1700	1150	1.05	1195	1.15	1240	1.28	1280	1.38	1320	1.50	1365	1.63	1400	1.75	1440	1.88
1800	1170	1.13	1215	1.23	1255	1.35	1300	1.48	1340	1.58	1380	1.73	1415	1.83	1455	1.98
1900	1195	1.23	1235	1.33	1275	1.43	1315	1.55	1355	1.68	1395	1.78	1435	1.93	1470	2.08
2000	1220	1.33	1260	1.43	1300	1.53	1340	1.68	1375	1.78	1415	1.93	1450	2.03	1485	2.18

**TABLE 5
BELT DRIVE BLOWER PERFORMANCE**

0.10 to 0.80 in. w.g.		5 Ton Standard Efficiency (Down-Flow)														KHA060S
Air Volume (cfm)	External Static (in.w.g.)															
	0.10		0.20		0.30		0.40		0.50		0.60		0.70		0.80	
	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP
	Field Furnished						Low Static - Drive Kit #3									
1600	675	0.30	730	0.35	785	0.40	835	0.45	885	0.50	935	0.60	985	0.65	1030	0.70
1700	710	0.35	760	0.40	815	0.45	860	0.50	910	0.60	960	0.65	1005	0.70	1050	0.80
1800	745	0.45	795	0.50	845	0.55	890	0.60	935	0.65	980	0.70	1025	0.80	1070	0.85
1900	780	0.50	830	0.55	875	0.60	920	0.65	965	0.75	1010	0.80	1050	0.85	1090	0.95
2000	820	0.60	865	0.65	905	0.70	950	0.75	990	0.80	1035	0.90	1075	0.95	1115	1.05
2100	855	0.65	900	0.70	940	0.80	980	0.85	1020	0.90	1060	1.00	1100	1.05	1140	1.15
2200	890	0.75	935	0.80	970	0.85	1010	0.95	1050	1.00	1090	1.10	1130	1.15	1165	1.25
2300	930	0.85	970	0.90	1005	1.00	1045	1.05	1080	1.10	1120	1.20	1155	1.25	1190	1.35
2400	965	0.95	1005	1.05	1040	1.10	1075	1.15	1115	1.25	1150	1.30	1185	1.40	1220	1.50
0.90 to 1.60 in. w.g.		5 Ton Standard Efficiency (Down-Flow)														KHA060S
Air Volume (cfm)	External Static (in.w.g.)															
	0.90		1.00		1.10		1.20		1.30		1.40		1.50		1.60	
	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP
	Low Static - Drive Kit #3						High Static - Drive Kit #7									
1600	1075	0.80	1120	0.85	1160	0.95	1200	1.05	1240	1.10	1280	1.20	1320	1.30	1355	1.35
1700	1090	0.85	1135	0.95	1175	1.00	1215	1.10	1255	1.20	1295	1.30	1330	1.35	1365	1.45
1800	1110	0.95	1155	1.00	1195	1.10	1230	1.20	1270	1.25	1310	1.35	1345	1.45	1380	1.55
1900	1135	1.05	1170	1.10	1210	1.20	1250	1.25	1285	1.35	1325	1.45	1360	1.55	1395	1.65
2000	1155	1.10	1195	1.20	1230	1.30	1270	1.35	1305	1.45	1340	1.55	1375	1.65	1410	1.75
2100	1180	1.20	1215	1.30	1250	1.40	1290	1.45	1325	1.55	1360	1.65	1395	1.75	1425	1.85
2200	1200	1.30	1240	1.40	1275	1.50	1310	1.60	1345	1.70	1380	1.80	1410	1.85	1445	1.95
2300	1225	1.45	1260	1.50	1295	1.60	1330	1.70	1365	1.80	1400	1.90	1430	2.00	1465	2.10
2400	1255	1.55	1285	1.65	1320	1.75	1355	1.85	1385	1.90	1420	2.05	1450	2.10	1480	2.20
0.10 to 0.80 in. w.g.		5 Ton Standard Efficiency (Horizontal)														KHA060S
Air Volume (cfm)	External Static (in.w.g.)															
	0.10		0.20		0.30		0.40		0.50		0.60		0.70		0.80	
	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP
	Field		Low Static - Drive Kit #3													
1600	785	0.40	845	0.45	900	0.50	955	0.55	1010	0.65	1060	0.70	1110	0.80	1160	0.90
1700	825	0.45	880	0.50	935	0.60	990	0.65	1040	0.70	1090	0.80	1135	0.85	1185	0.95
1800	865	0.50	920	0.60	975	0.65	1020	0.75	1070	0.80	1120	0.90	1165	0.95	1210	1.05
1900	910	0.60	960	0.70	1010	0.75	1060	0.85	1105	0.90	1150	1.00	1195	1.05	1240	1.15
2000	950	0.70	1000	0.80	1050	0.85	1095	0.95	1140	1.00	1185	1.10	1225	1.15	1265	1.25
2100	995	0.80	1040	0.90	1085	0.95	1130	1.05	1175	1.15	1215	1.20	1260	1.30	1300	1.40
2200	1040	0.95	1085	1.00	1125	1.10	1170	1.15	1210	1.25	1250	1.35	1290	1.40	1330	1.50
2300	1080	1.05	1125	1.15	1165	1.20	1205	1.30	1245	1.40	1285	1.45	1325	1.55	1360	1.65
2400	1125	1.20	1165	1.25	1205	1.35	1245	1.45	1285	1.55	1320	1.60	1360	1.70	1395	1.80
0.90 to 1.60 in. w.g.		5 Ton Standard Efficiency (Horizontal)														KHA060S
Air Volume (cfm)	External Static (in.w.g.)															
	0.90		1.00		1.10		1.20		1.30		1.40		1.50		1.60	
	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP
	Drive Kit #3		High Static - Drive Kit #7													
1600	1210	0.95	1255	1.05	1305	1.15	1350	1.30	1395	1.40	1440	1.55	1485	1.65	1530	1.80
1700	1230	1.05	1275	1.15	1320	1.25	1365	1.35	1410	1.45	1455	1.60	1495	1.70	1540	1.85
1800	1255	1.15	1300	1.25	1340	1.35	1385	1.45	1425	1.55	1470	1.70	1510	1.80	1550	1.95
1900	1280	1.25	1325	1.35	1365	1.45	1405	1.55	1445	1.65	1485	1.75	1525	1.90	1565	2.00
2000	1310	1.35	1350	1.45	1390	1.55	1430	1.65	1470	1.75	1505	1.85	1545	2.00	1585	2.15
2100	1340	1.50	1375	1.55	1415	1.65	1455	1.80	1490	1.90	1530	2.00	1565	2.10	1605	2.25
2200	1370	1.60	1405	1.70	1445	1.80	1480	1.90	1515	2.00	1555	2.15	1590	2.25	1625	2.40
2300	1400	1.75	1435	1.85	1470	1.95	1510	2.05	1545	2.20	1580	2.30	1615	2.40	1650	2.55
2400	1430	1.90	1465	2.00	1505	2.15	1535	2.20	1570	2.35	1605	2.45	1640	2.60	1675	2.70

**TABLE 6
BELT DRIVE BLOWER PERFORMANCE**

0.10 to 0.80 in. w.g.

6 Ton Standard Efficiency (Downflow)

KHA072S

Air Volume (cfm)	External Static (in.w.g.)															
	0.10		0.20		0.30		0.40		0.50		0.60		0.70		0.80	
	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP
Field Furnished											Low Static - Drive Kit A04					
1900	752	0.48	803	0.53	855	0.58	903	0.62	957	0.72	1008	0.78	1066	0.88	1118	0.92
2000	793	0.52	845	0.62	892	0.68	940	0.73	990	0.77	1041	0.88	1093	0.93	1144	1.03
2100	838	0.64	881	0.68	929	0.73	978	0.83	1023	0.88	1073	0.93	1124	1.03	1169	1.14
2200	880	0.73	923	0.78	966	0.84	1015	0.93	1061	0.99	1104	1.03	1149	1.13	1198	1.24
2300	921	0.83	966	0.89	1009	0.93	1053	0.99	1097	1.09	1139	1.15	1183	1.25	1220	1.35
2400	964	0.94	1007	0.99	1046	1.05	1089	1.14	1127	1.19	1168	1.29	1211	1.35	1247	1.45
2500	1006	1.05	1044	1.09	1087	1.14	1124	1.25	1160	1.30	1201	1.40	1238	1.51	1274	1.56
2600	1047	1.15	1085	1.20	1121	1.30	1157	1.36	1197	1.46	1234	1.56	1269	1.62	1304	1.72
2700	1094	1.31	1124	1.37	1159	1.41	1195	1.52	1229	1.62	1265	1.67	1295	1.77	1330	1.88
2800	1133	1.42	1162	1.52	1196	1.57	1226	1.67	1260	1.73	1295	1.83	1325	1.94	1360	2.04
2900	1170	1.58	1204	1.68	1232	1.73	1261	1.84	1290	1.89	1326	2.00	1356	2.09	1386	2.19

0.90 to 1.60 in. w.g.

6 Ton Standard Efficiency (Downflow)

KHA072S

Air Volume (cfm)	External Static (in.w.g.)															
	0.90		1.00		1.10		1.20		1.30		1.40		1.50		1.60	
	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP
High Static - Kit A08																
1900	1170	1.03	1216	1.12	1261	1.23	1299	1.28	1338	1.39	1381	1.49	1423	1.59	1462	1.69
2000	1190	1.13	1238	1.18	1279	1.28	1317	1.39	1356	1.49	1397	1.59	1434	1.69	1476	1.80
2100	1213	1.19	1261	1.29	1300	1.39	1339	1.49	1373	1.60	1414	1.70	1449	1.79	1490	1.90
2200	1241	1.30	1282	1.39	1316	1.50	1355	1.60	1394	1.70	1429	1.79	1463	1.90	1498	1.99
2300	1263	1.39	1303	1.50	1337	1.60	1376	1.70	1409	1.80	1444	1.90	1483	2.04	1517	2.14
2400	1289	1.55	1323	1.61	1362	1.76	1397	1.86	1430	1.96	1464	2.05	1498	2.15	1532	2.25
2500	1314	1.66	1349	1.76	1383	1.87	1416	1.96	1451	2.06	1484	2.15	1517	2.24	1545	2.34
2600	1340	1.82	1374	1.92	1408	2.02	1438	2.12	1471	2.21	1505	2.30	1532	2.39	1565	2.49
2700	1365	1.98	1399	2.08	1429	2.12	1463	2.27	1497	2.36	1525	2.45	1558	2.55	1585	2.63
2800	1390	2.08	1425	2.24	1454	2.27	1488	2.42	1517	2.51	1545	2.60	1578	2.69	1605	2.84
2900	1421	2.28	1451	2.39	1480	2.47	1514	2.57	1543	2.65	1570	2.75	1597	2.89	1625	2.99

Note - **BOLD** - to operate in this range, 3 hp blower motor is required.

**TABLE 7
BELT DRIVE BLOWER PERFORMANCE**

0.10 to 0.80 in. w.g.

6 Ton Standard Efficiency (Horizontal)

KHA072S

Air Volume (cfm)	External Static (in.w.g.)															
	0.10		0.20		0.30		0.40		0.50		0.60		0.70		0.80	
	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP
	Field		Low Static - Drive Kit A04													
1900	919	0.60	969	0.65	1020	0.74	1065	0.79	1111	0.83	1154	0.93	1194	0.99	1232	1.04
2000	962	0.70	1013	0.75	1058	0.84	1103	0.90	1148	0.94	1186	1.04	1226	1.09	1264	1.15
2100	1010	0.80	1056	0.85	1101	0.95	1146	0.99	1185	1.05	1223	1.15	1262	1.20	1296	1.30
2200	1054	0.91	1099	0.95	1143	1.06	1183	1.10	1222	1.21	1261	1.25	1295	1.36	1333	1.41
2300	1102	1.01	1142	1.11	1182	1.16	1220	1.26	1258	1.31	1297	1.42	1330	1.46	1364	1.57
2400	1146	1.16	1184	1.21	1224	1.32	1262	1.37	1300	1.47	1333	1.58	1367	1.63	1401	1.72
2500	1188	1.27	1227	1.38	1265	1.48	1303	1.53	1336	1.63	1370	1.73	1404	1.79	1438	1.88
2600	1235	1.44	1273	1.55	1306	1.65	1339	1.70	1378	1.79	1407	1.89	1441	1.99	1475	2.03
2700	1276	1.61	1314	1.71	1347	1.81	1380	1.91	1414	2.00	1449	2.05	1478	2.14	1512	2.23
2800	1321	1.82	1354	1.92	1388	1.97	1421	2.07	1456	2.16	1485	2.25	1519	2.34	1549	2.44
2900	1367	2.03	1400	2.08	1429	2.17	1463	2.27	1497	2.36	1526	2.45	1556	2.54	1586	2.63

0.90 to 1.60 in. w.g.

6 Ton Standard Efficiency (Horizontal)

KHA072S

Air Volume (cfm)	External Static (in.w.g.)															
	0.90		1.00		1.10		1.20		1.30		1.40		1.50		1.60	
	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP
	Drive Kit A04				High Static - Kit A08											
1900	1271	1.13	1310	1.18	1345	1.24	1380	1.34	1421	1.39	1458	1.50	1493	1.60	1524	1.65
2000	1303	1.24	1337	1.29	1371	1.40	1412	1.45	1448	1.55	1485	1.61	1516	1.70	1551	1.75
2100	1335	1.36	1370	1.45	1404	1.50	1439	1.60	1476	1.65	1512	1.76	1544	1.81	1579	1.90
2200	1367	1.51	1401	1.56	1436	1.66	1472	1.71	1503	1.81	1540	1.91	1570	1.96	1606	2.06
2300	1398	1.62	1433	1.71	1468	1.81	1503	1.86	1535	1.97	1567	2.02	1603	2.11	1633	2.21
2400	1436	1.78	1470	1.87	1501	1.96	1535	2.01	1567	2.12	1600	2.22	1630	2.27	1660	2.36
2500	1473	1.98	1503	2.03	1533	2.12	1568	2.21	1599	2.27	1631	2.37	1662	2.47	1693	2.57
2600	1505	2.13	1539	2.23	1570	2.32	1600	2.37	1632	2.47	1664	2.57	1694	2.67	1725	2.77
2700	1542	2.33	1572	2.37	1607	2.47	1638	2.57	1664	2.67	1696	2.77	1726	2.87	1757	2.97
2800	1579	2.53	1609	2.58	1640	2.68	1670	2.77	1701	2.87	1732	2.96	1758	3.07	1789	3.16
2900	1616	2.73	1646	2.83	1676	2.92	1708	3.02	1733	3.06	1764	3.17	1794	3.31	1821	3.37

Note - **BOLD** - to operate in this range, 3 hp blower motor is required.

**TABLE 8
ADDITIONAL ACCESSORY AIR RESISTANCE**

Air Volume cfm	Economizer	Electric Heat
800	0.04	0.01
1000	0.04	0.03
1200	0.04	0.06
1400	0.04	0.09
1600	0.04	0.12
1800	0.05	0.15
2000	0.05	0.18
2200	0.05	0.20
2400	0.05	0.22
2600	0.06	0.24
2800	0.06	0.26
3000	0.06	0.28

**TABLE 9
MINIMUM AIRFLOW
KH(BELT DRIVE) UNITS WITH ELECTRIC HEAT**

Kw	CFM	
	Downflow	Horizontal
30	2250	2050
22.5	1750	1800
15	1250	1350
7.5	1050	1200

Direct drive units with electric heat (7.5-22.5kW) can operate on low speed up to 0.6" w.g. maximum static pressure.

**TABLE 10
DRIVE COMPONENT MANUFACTURER'S NUMBERS**

Drive No.	DRIVE COMPONENTS					
	MOTOR PULLEY		BLOWER PULLEY		BELTS	
	Browning No.	OEM Part No.	Browning No.	OEM Part No.	Browning No.	OEM Part No.
A01	1VP34 X 3/8	31K6901	AK54 X 1	100244-19	A40	100245-17
A02	1VP34 X 3/8	31K6901	AK49 X 1	100244-18	A39	100245-16
A03	1VP34 X 3/8	31K6901	AK44X 1	100244-16	A39	100245-16
A04	1VP40 X 3/8	79J0301	AK49 X 1	100244-18	A41	100245-18
A05	1VP34 X 3/8	31K6901	AK41 X 1	100244-15	A38	100245-15
A06	1VP44 X 3/8	P-8-1488	AK51 X 1	18L2201	A41	100245-18
A07	1VP50 X 3/8	53J1501	AK54 X 1	100244-19	AX43	73K8201
A08	1VP44 X 3/8	P-8-1488	AK46 X 1	100244-17	A40	100245-17

**TABLE 11
DRIVE KIT SPECIFICATIONS**

Motor hp		RPM Range							
Nominal	Maximum	Drive A01	Drive A02	Drive A03	Drive A04	Drive A05	Drive A06	Drive A07	Drive A08
1.5	1.72	673 - 1010	745 - 1117	833 - 1250	968 - 1340	897 - 1346	1071 - 1429	1212 - 1548	1193 - 1591
2	2.3								

*Using total air volume and system static pressure requirements determine from blower performance tables rpm and motor hp required. Maximum usable hp of motors furnished by Lennox are shown. In Canada, nominal motor hp is also maximum usable motor hp. If motors of comparable hp are used, be sure to keep within the service factor limitations outlined on the motor nameplate.

Start-Up

▲ IMPORTANT
If unit is equipped with a crankcase heater. Make sure heater is energized 24 hours before unit start-up to prevent compressor damage as a result of slugging.

A-Start-Up

Heating

- 1- Set thermostat or temperature control device to initiate a first-stage heating demand.

- 2- A first-stage heating demand (W1) will energize compressors 1 and the outdoor fan.

Note - L1 reversing valve is de-energized in the heating mode.

KHA Units With Optional Electric Heat -

An increased heating demand (W2) will energize electric heat. Electric heat is also energized during the defrost cycle (W1) to maintain discharge air temperature.

Cooling

- 1- Set thermostat or temperature control device fan switch to **AUTO** or **ON**. Set thermostat or temperature control device to initiate a first-stage cooling demand.

A first-stage Y1 cooling demand will energize L1 reversing valve solenoid and compressor 1.

Units With Optional Economizer -

The optional economizer will start on a first stage (Y1) cooling demand when outdoor air enthalpy is suitable. An increased cooling demand (Y2) will energize compressor 1.

- 2- Refrigerant circuits are factory charged with either R-22 or R-410A refrigerant. See unit rating plate for correct amount of charge.

B-Three Phase Scroll Compressor Voltage Phasing

Three phase scroll compressors must be phased sequentially to ensure correct compressor and blower rotation and operation. Compressor and blower are wired in phase at the factory. Power wires are color-coded as follows: line 1-red, line 2-yellow, line 3-blue.

- 1- Observe suction and discharge pressures and blower rotation on unit start-up.
- 2- Suction pressure must drop, discharge pressure must rise, and blower rotation must match rotation marking.

If pressure differential is not observed or blower rotation is not correct:

- 3- Disconnect all remote electrical power supplies.
- 4- Reverse any two field-installed wires connected to the line side of K1 contactor. Do not reverse wires at blower contactor.

Make sure the connections are tight.

Discharge and suction pressures should operate at their normal start-up ranges.

C - Refrigerant Charge and Check

WARNING-Do not exceed nameplate charge under any condition.

This unit is factory charged and should require no further adjustment. If the system requires charge, **reclaim the charge, evacuate the system, and add required nameplate charge.**

*NOTE - System charging is not recommended below 60°F (15°C). In temperatures below 60°F (15°C) , the charge **must** be weighed into the system.*

If weighing facilities are not available, or to check the charge, use the following procedure:

- 1- Attach gauge manifolds and operate unit in cooling mode until system stabilizes (approximately five minutes).
- 2- Check each system separately with all stages operating.
- 3- Use a thermometer to accurately measure the outdoor ambient temperature.

- 4- Apply the outdoor temperature to tables 12 through 17 to determine normal operating pressures.

- 5- Compare the normal operating pressures to the pressures obtained from the gauges. Minor variations in these pressures may be expected due to differences in installations. Significant differences could mean that the system is not properly charged or that a problem exists with some component in the system. **Correct any system problems before proceeding.**

**TABLE 12
TH 024S R22 NORMAL OPERATING PRESSURES**

Outdoor Coil Entering Air Temp	Dis. ± 10 psig	Suct. ±5 psig
65°F	226	147
75°F	258	148
85°F	304	151
95°F	351	154
105°F	402	157
115°F	460	160

**TABLE 13
KH 030S R410A NORMAL OPERATING PRESSURES**

Outdoor Coil Entering Air Temp	Dis. ± 10 psig	Suct. ±5 psig
65°F	235	145
75°F	273	148
85°F	316	151
95°F	363	153
105°F	416	156
115°F	476	158

**TABLE 14
KH R410A 036S NORMAL OPERATING PRESSURES**

Outdoor Coil Entering Air Temp	Dis. ± 10 psig	Suct. ±5 psig
65°F	247	140
75°F	289	143
85°F	331	145
95°F	381	148
105°F	434	151
115°F	492	154

**TABLE 15
KH 048S R410A NORMAL OPERATING PRESSURES**

Outdoor Coil Entering Air Temp	Dis. ± 10 psig	Suct. ±5 psig
65°F	272	139
75°F	313	142
85°F	359	145
95°F	410	148
105°F	465	150
115°F	529	152

TABLE 16
KH 060S R410A NORMAL OPERATING PRESSURES

Outdoor Coil Entering Air Temp	Dis. \pm 10 psig	Suct. \pm 5 psig
65°F	265	136
75°F	304	139
85°F	348	141
95°F	397	144
105°F	447	147
115°F	507	149

TABLE 17
KH 072S R410A NORMAL OPERATING PRESSURES

Outdoor Coil Entering Air Temp	Dis. \pm 10 psig	Suct. \pm 5 psig
65°F	257	134
75°F	297	138
85°F	340	142
95°F	387	146
105°F	438	149
115°F	493	153

6- If discharge pressure is high, remove refrigerant from the system. If discharge pressure is low, add refrigerant to the system.

- Add or remove charge in increments.
- Allow the system to stabilize each time refrigerant is added or removed.

7- Use the following approach method along with the normal operating pressures to confirm readings.

D - Charge Verification - Approach Method

1- Using the same thermometer, compare liquid temperature to outdoor ambient temperature.

Approach Temperature = Liquid temperature minus ambient temperature.

2- Approach temperature should match values in table 18. An approach temperature greater than value shown indicates an undercharge. An approach temperature less than value shown indicates an overcharge.

3- Do not use the approach method if system pressures do not match pressures in tables 12 through 17. The approach method is not valid for grossly over or undercharged systems.

TABLE 18
APPROACH TEMPERATURE

Unit	Liquid Temp. Minus Ambient Temp.
KH 024	7°F \pm 1 (3.9°C \pm 0.5)
KH 030S, 036S	9°F \pm 1 (5.0°C \pm 0.5)
KH 048S, 060S	11°F \pm 1 (6.1°C \pm 0.5)
KH 072S	8°F \pm 1 (4.4°C \pm 0.5)

E - Compressor Controls

See unit wiring diagram to determine which controls are used in each unit. Optional controls are identified on wiring diagrams by arrows at junction points.

1- Freezestat (S49)

Switch de-energizes compressor when indoor coil temperature falls below 29°F (-2°C) to prevent coil freeze-up. Switch resets when indoor coil temperature reaches 58°F (15°C).

2- Defrost Switch (S6)

Defrost switch closes to initiate defrost when liquid line temperature falls to 42°F (5.6°C). Defrost switch opens when liquid line temperature reaches 70°F (21°C) to terminate defrost. If the liquid line temperature does not rise above 70°F (21°C), the CMC1 will terminate defrost after 14 minutes. The defrost switch is located on the liquid line between the outdoor expansion valve and the distributor

3- Defrost Control (CMC1)

Defrost is liquid line temperature initiated and operates for 14 minutes unless terminated by liquid line temperature.

When the liquid line temperature drops below 42°F (5.6°C), the defrost switch closes and signals the **defrost control** that a defrost cycle is needed. If the defrost switch is still closed after 60 minutes (default), a defrost cycle begins and operates for 14 minutes. The defrost switch can terminate the defrost cycle before the 14 minutes elapses if liquid line temperature reaches 70°F (21°C)

Electric heat is energized during defrost to maintain discharge air temperature.

Defrost Control Board

The defrost thermostat and the defrost control work together to ensure that the heat pump outdoor coil does not ice excessively during the heating mode.

Compressor Accumulated Run-Time Interval

The defrost control will not energize a defrost cycle unless the unit has been operating in heating mode for an accumulated 60 minutes (default) on 100269-02 boards; 90 minutes (default) on 100269-04 boards. The run time interval can be changed by moving the jumper on the CMC board timing pins. See figure 18.




FIGURE 18

The defrost interval can be adjusted to 30, 60, or 90 minutes. The defrost timing jumper is factory-installed to provide a 60-minute defrost interval. If the timing selector jumper is not in place, the control defaults to a 90-minute defrost interval.

Defrost Test Option

A TEST option is provided for troubleshooting. The TEST mode may be started any time the unit is in the heating mode and the defrost thermostat is closed or jumpered. If the timing jumper is in the TEST position at power-up, the defrost control will ignore the test pins. When the jumper is placed across the TEST pins for two seconds, the control will enter the defrost mode. If the jumper is

removed before an additional 5-second period has elapsed (7 seconds total), the unit will remain in defrost mode until the defrost pressure switch opens or 14 minutes have passed. If the jumper is not removed until after the additional 5-second period has elapsed, the defrost will terminate and the test option will not function again until the jumper is removed and re-applied.

Diagnostic LEDs

The defrost board uses two LEDs for diagnostics. The LEDs flash a sequence according to the condition.

TABLE 19

Defrost Control Board Diagnostic LED		
Mode	Green LED (DS2)	Red LED (DS1)
No power to control	OFF	OFF
Normal operation / power to control	Simultaneous Slow FLASH	
Anti-short cycle lockout	Alternating Slow FLASH	
Low pressure switch, freezestat fault	OFF	Slow FLASH
Low pressure switch, freezestat lockout	OFF	ON
High pressure switch fault	Slow FLASH	OFF
High pressure switch lockout	ON	OFF

Service

The unit should be inspected once a year by a qualified service technician.

⚠ WARNING

Product contains fiberglass wool. Disturbing the insulation in this product during installation, maintenance, or repair will expose you to fiberglass wool. Breathing this may cause lung cancer. (Fiberglass wool is known to the State of California to cause cancer.)

Fiberglass wool may also cause respiratory, skin, and eye irritation.

To reduce exposure to this substance or for further information, consult material safety data sheets available from address shown on unit nameplate or contact your supervisor.

⚠ CAUTION

Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation. Verify proper operation after servicing.

A - Lubrication

All motors are lubricated at the factory. No further lubrication is required.

B-Compressor

If Interlink compressor replacement is necessary, call 1-800-4-LENNOX (1-800-453-6669).

⚠ IMPORTANT

Some scroll compressors have an internal vacuum protector that will unload scrolls when suction pressure goes below 20 psig. A hissing sound will be heard when the compressor is running unloaded. Protector will reset when low pressure in system rises above 40 psig. **DO NOT REPLACE COMPRESSOR.**

C - Filters

Units are equipped with temporary filters which need to be replaced before the building is occupied. See table 20 for correct filter size. Refer to local codes or appropriate jurisdiction for approved filters.

Approved filters should be checked monthly and replaced when necessary. Take note of air flow direction marking on filter frame when reinstalling filters. See figure 19.

⚠ WARNING

Units are shipped from the factory with temporary filters. Replace filters before building is occupied. Damage to unit could result if filters are not replaced with approved filters. Refer to appropriate codes.

**TABLE 20
UNIT FILTERS**

Unit	Qty	Filter Size - inches (mm)
024, 030, 036, 048, 060B	4	16 X 20 X 2 (406 X 508 X 51)
060S, 072	4	20 X 20 X 2 (508 X 508 X 51)

NOTE-Filters must be U.L.C. certified or equivalent for use in Canada.

D - Supply Air Blower Wheel

Annually inspect supply air blower wheel for accumulated dirt or dust. Turn off power before attempting to remove access panel or to clean blower wheel.

E - Indoor Coil

Inspect and clean coil at beginning of each cooling and heating season. Clean using mild detergent or commercial coil cleanser. Flush coil and condensate drain with water taking care not to get insulation, filters and return air ducts wet.

F - Outdoor Coil

Clean outdoor coil annually with detergent or commercial coil cleaner and inspect monthly during the cooling season.

Outdoor coils are made of single and two formed slabs. On units with two slabs, dirt and debris may become trapped between the slabs. To clean between slabs, carefully separate coil slabs and wash them thoroughly. See figure 20. Flush coils with water following cleaning.

Note - Remove all screws and gaskets prior to cleaning procedure and replace upon completion.

G - Filter Drier

The unit is equipped with a biflow filter drier. If replacement is necessary, order another of like design.





FIGURE 19



- 1- Remove screws securing coil end plate to mullion.
- 2- Remove wire ties connecting coils slabs and separate slabs 3-4" (76-102mm).
- 3- Clean coils with detergent or commercial coil cleaner.
- 4- Rinse thoroughly with water and reassemble.
- 5- Secure coil slabs together using field-provided wire ties.

FIGURE 20